bob rudd
gaming & amusement machines

Part of THE RUDD GROUP

IMPORTANT

THE IMPORTANCE OF REFILLING



If the beer runs out at 7pm do you change the barrel?
If you sell out of sandwiches at 1pm do you make more?
So when the fruit machine runs low why not fill it?
One of the most profitable areas in your pub is the 2sq ft taken up by the fruit machine.

WHY SHOULD YOU REFILL?

More than 80% of the money fed into the machine will be in notes however most payouts will be in coins therefore when the hopper drops below £100 the note acceptor will cut out to prevent any more notes being inserted. For core players this is a warning sign that the machine has recently paid out a lot of money and therefore is unlikely to pay out again soon. This will deter customers from playing your machine. Some core players even have their own refill keys that they will use to check the float levels; low levels will prevent them from playing.

HOW TO REFILL

Turn the refill key and record the meter. Then refill to the amount shown. Ensure you then take the meter after refilling and note the refill amount on your pro forma. The collector will then reimburse you in full. To maximise the profit of you machine be sure to refill everyday!